


CONNECTORS - POWER

HOT RUNNER TEMP CONTROL



MC5TC-FB
5 ZONE

MC8TC-FB
8 ZONE



MC12TC-FB
12 ZONE

CONNECTORS - THERMOCOUPLE

5 ZONE

8 ZONE

12 ZONE



MC5TC-FB

MC8TC-FB

MC12TC-FB

PART#	MTC-5	MTC-8	MTC-12
ZONES	5	8	12
L(in)	3.662	4.449	5.512
A(in)	3.268	4.055	5.118

CABLES - POWER & THERMOCOUPLE

POWER CABLES



MC5P-X 5-ZONE "X" ft
MC8P-X 8-ZONE "X" ft
MC12P-X 12-ZONE "X" ft

T/C CABLE 5 ZONE



MC5TC-10 10ft CABLE
MC5TC-20 20ft CABLE

T/C CABLE 8 ZONE




MC8TC-10 10ft CABLE
MC8TC-20 20ft CABLE

T/C CABLE 12 ZONE




MC12TC-10 10ft
MC12TC-20 20ft

POWER CONNECTOR



THERMOCOUPLE CONNECTOR



ZONE	ROW	TERMINAL
1	A	1 & 2
2	A	3 & 4
3	A	5 & 6
4	A	7 & 8
5	B	2 & 3
6	B	4 & 5

ZONE	ROW	TERMINAL
7	B	6 & 7
8	C	1 & 2
9	C	3 & 4
10	C	5 & 6
11	C	7 & 8
12	A & C	9

5, 8, 12+ ZONE - TERMINAL MOUNTING BOXES



SINGLE CONNECTOR BOXES



POWER & THERMOCOUPLE BOXES

SINGLE CONNECTOR BOXES

PART#	TYPE	L (in)	W (in)	D (in)
MTB-P	POWER	4.9	3	4
MTB-5TC	T/C - 5 ZONE	4.9	3	4
MTB-8TC	T/C - 8 ZONE	6.7	3	4
MTB-12TC	T/C 12 ZONE	6.7	3	4

POWER & THERMOCOUPLE CONNECTOR BOXES

PART#	TYPE	L (in)	W (in)	D (in)
MTB-P5TC	5 ZONE	10.5	3	4
MTB-P8TC	8 ZONE	10.5	3	4
MTB-P12TC	12 ZONE	10.5	3	4

COVER PLATE, STAND, TRANSFORMER KIT




MC-COVER
TO COVER
EMPTY ZONES

TRANSFORMER KITS
PLEASE INQUIRE




MC-STAND
for 5-48 zones



1 ZONE SYSTEM

HOT RUNNER TEMP CONTROL




MP1-C10 10FT CABLE
MP1-C20 20FT CABLE



MP1F-B CONNECTOR
MTB-P1TC TERM BOX

2 ZONE SYSTEM




MP1-C10 (x2) 10FT CABLE
MP1-C20 (x2) 20FT CABLE



MP1F-B (x2) CONNECTOR
MTB-P2TC TERM BOX

3 ZONE SYSTEM



MP1-C10 (x3) 10FT CABLE
MP1-C20 (x3) 20FT CABLE



MP1F-B (x3) CONNECTOR
MTB-P3TC TERM BOX

CONNECTORS - 1, 2, 3 ZONE



MP1F-B



MP1M-B



MP1M-H



MP1F-H



MP1F-HL



MP1M-HL